

Replacement Bucket Instructions

Step One

Inspect swivel mounted to chair or stool base; locate word FRONT.

Place swivel with word FRONT on the swivel on bottom of seat with the word FRONT facing the front of the seat.

If your swivel is not stamped front you have a universal swivel.

Step Two

The seat bottom has 4 holes with 1/4" "T" nuts installed.

Use the 4-1/4"x3/4" machine screws to attach swivel to seat base.

Do not force screws into holes with "T" nuts you could dislodge the "T" nuts and would be unable to attach seat to swivel.

Start all screws first with your fingers then use a screw driver or cordless drill to tighten.

If your swivel base holes don't match our mounting holes use the 4 wood screws and lock washers to mount seat to your base.

You are now ready to use you new bucket.

Do not use impact cordless drill to attach seat.

When using cordless drill with adjustable chuck, set drill speed to slow speed.

Set chuck torque to low torque. This will eliminate stripping screw in the seat.