

Bucket Chair with Casters Instructions

Step One

Install 4 castors in base.

Step Two

Inspect swivel mounted to chair base; locate word FRONT.

Place swivel with word FRONT on the swivel on bottom of seat with the word FRONT facing the front of the seat.

Step Three

The seat bottom has 4 holes with 1/4" "T" nuts installed.

Use the 4-1/4"x3/4" machine screws to attach swivel to seat base.

Do not force screws into holes with "T" nuts you could dislodge the "T" nuts and would be unable to attach seat to swivel.

Start all screws first with your fingers then use a screw driver or cordless drill to tighten.

You are ready to use your chair.